

“SUPRALUX” INKS

series 107

PRINT TYPE	Flexographic.
MAIN SUBSTRATE	Tissue paper (Flimsy).
RECOMMENDED THINNERS	Ethanol 99.9°/Ethyl Acetate mixtures in various ratios (e.g. 80/20). Our specific diluent: “DILUENTE 70/30” (“70/30 DILUENT”), code 100D/003.
RETARDER	Methoxypropanol (e.g. Dowanol PM) or other alkyloxy propanols, glycolethers (e.g. Cellosolve). Our specific retarder: “RITARDANTE SUPRALUX” (“SUPRALUX RETARDER”), code 107D/005.
CLICHE’	Photopolymeric clichè can be used which have Alcohol/Acetate mixture fastness or butyl rubber rollers.
FEATURES	Inks suitable for tissue paper (Flimsy) printing. Good scratch and rubbing resistance.
NOTES	Shake the ink before use.
EXPIRY DATE AND STORAGE	The quality of the product is ensured for 12 months from the manufacture date with the product kept in the original sealed containers. A storage temperature of 20°C is suggested.
STANDARD PACKAGING	Pails 20-25 Kg; drums 170 Kg; tanks 500-900 Kg.



*The aim of these technical data sheets is to inform the customers about our products, but they can not include all printing situations.
For this reason the particularities of all printing processes must be considered before use of the described products and we suggest to contact us for further informations.*